

SOFTWARE

Mach4



Mach4


Graphical interface to control machine

Interpret G code

Mill, lathe, router, plasma cutter, laser cutter.

Calculate trajectory of tool

Communicate moves to motion control.



Motion control



Ethernet Smoothstepper

Converts commands from Mach4 into stepper motor pulses.



Set up PC

Mach4 requires a PC running Windows 10 or 11. Use common windows setup, no extra software is needed, or desired, this PC should only be used as a machine control.

Install Mach4 from memory stick, Or download file from downloads tab at <https://machsupport.com>

Also requires a plugin from Warp9 tech on the memory stick or Download from <https://warp9td.com>

Documents

Mach4 provides many manuals when installed

`C:\Mach4Hobby\Docs`

The ESS has many pages of on-line documentation

`https://Warp9td.com`

This document is a simplified guide to the installation.

If questions arise see the above sources.

Mach4 Profile

A PC can be setup to run several different machines.

Each machine has a separate configuration appropriate to that machine.

The configuration is saved in a folder `C:\Mach4Hobby\Profiles`

When installing Mach4 you will be asked for a profile. Create a meaningful name.

In the sample screens here we used `MyLathe` as profile name.

DO NOT use one of the system profile names, it will be overwritten if you upgrade the software.

Optional profile

We have provided a profile suitable for the LMS 5100

We called it MyLathe.

A copy is on the memory stick.

Copy the file from the stick and put it in the profile folder.

`C:\Mach4Hobby\Profiles`

All of the following configuration steps are completed in this profile.

Profile (2)


The Mach4 install will create some desktop icons.

Right click on the icon for Mill.

Select Properties

The Target line will have the start command for Mach4, followed by the profile name. Edit this to the name you have given your profile.


You can now start Mach4 with a double click



Profile (3)

Change to the General tab

Replace the name with
your profile name.




Needs new
image

Mach4 Install

Find the install file.


Double click it.



Mach4 Install

Check to accept license terms


Click Next



Mach4 Install

Observe the warning message!


Click Next



Mach4 Install


UnCheck type of machines you are not using.

Click Install




Mach4 Install

Wait for progress bar



Mach4 Install

Click Finish




Mach4 Install

Mach4 will start and show the profile select screen.

Select Your profile then
Copy

Click OK



Screen Set

Mach4 has a built in screen editor

You may use it to modify any part of a screen

You may add or remove buttons.

You may change colors or type fonts.

You may add controls.

Screens can be fully customized, but start with one of the pre-built screens

You may switch screens at any time during operation.


Mach4 Install

New Image?

Copy profile will ask for screen choice.

Select wxLathe set for Lathe

Click “Open”




Mach4 Install

As Mach4 Starts it will try to use some internal network functions.

Windows will show this block warning.

This will only happen on the first time start up.

Allow access




Mach4 Install

SUCCESS! Mach4
is installed.

Before we can run
we need to install a
plugin for motion
control.

Stop Mach4 with
the X




Mach4 Install

Mach4 will build a screen icon for each machine type you selected.

Convert one of them to be your profile.

Right click on the icon and select Properties



Change the profile name to the profile you created.


Mach4 Install

Change to the
General tab

Change the name to
your profile name

Click OK

The desktop icon will
now start Mach4 with
your custom profile.



ESS- Ethernet Smooth Stepper

The motion control- ESS- requires a software driver, called a plugin.

It is supplied on the memory stick with this system.

To check for a newer version look at <https://warp9td.com/>

Download the .zip file **ESS_Mach4_v298.zip**

298 indicates the version number.

Open the .zip file and copy the two files


ESS plugin install

Using File Explorer navigate to
c:\Mach4Hobby\Plugins

Paste the two files into this
folder

Warp9Mach4.sig

Warp9Mach4.m4pw




Mach4 Install

Double click your profile Mach4 icon

When Mach4 starts select the *configure* menu bar item

Select Control



Mach4 Install

Select the ESS plugin

Click OK

Shutdown Mach4

Restart Mach4 to start the ESS plugin.

Control Configuration MyMill:0

Defaults General Plugins Motors Aux. Positions Axis Mapping Hom				
	Enabled	Description	Version	
1	✓	Core - Newfangled Solutions	4.2.0.5036	
2	✓	Keyboard Inputs - Newfangled Solutions	4.2.0.5036	
3	✓	LUA - Newfangled Solutions	4.2.0.5036	
4	✗	Modbus - Newfangled Solutions	4.2.0.5036	
5	✓	Regfile - Newfangled Solutions	4.2.0.5036	
6	✗	Serial - Newfangled Solutions	4.2.0.5036	
7	✗	Surface Map - Newfangled Solutions	4.2.0.5036	
8	✗	XBox Controller - DazTheGas and Newfangled	2.1.3	
9	✗	XhcMpg - Newfangled Solutions	4.2.0.5036	
10	✓	ShuttlePro - Newfangled Solutions	4.2.0.5036	
11	✓	Simulator - Newfangled Solutions	4.2.0.5036	
12	✗	WarpRunner v 002 - Warp9 Tech Design, Inc.	0.002	
13	✓	ESS v284 - Warp9 Tech Design, Inc.	1.0.1.284	

Mach4 Install


When Mach4 starts select
Configure

Select motion device

Choose ESS

Click OK

Shutdown Mach4



ESS setup



Browse to <https://warp9td.com>

Follow the directions to download the SCU application. There is also a great amount of background on setting up the ESS

ESS setup

The screenshot shows a web browser window with the URL <https://warp9td.com/index.php/sw>. The website header features the Warp9 Tech Design, Inc. logo and a navigation menu with the following items: Home, Product Details, Getting Started, Help, Software (highlighted), Documentation, FAQ, Forum, Order, Distributors, Solution Partners, Break Out Boards, Register for Forum, and Privacy. Below the navigation menu, the page is titled "Current Software Page". Under this title, the text "Which piece of software are you looking for:" is followed by a list of software options:


- [SCU \(System Configuration Utility\) for ESS \(Ethernet SmoothStepper\)](#)
- [Mach4 Plugin for ESS \(Ethernet SmoothStepper\)](#)
- [Mach3 Plugin for ESS \(Ethernet SmoothStepper\)](#)
- [Configurator for ESS \(Ethernet SmoothStepper\)](#)
- [Windows Driver for USS \(USB SmoothStepper\)](#)
- [Mach4 Plugin for USS \(USB SmoothStepper\)](#)
- [Mach3 Plugin for USS \(USB SmoothStepper\)](#)

A red arrow points from the text "Select the SCU" to the first option in the list: "SCU (System Configuration Utility) for ESS (Ethernet SmoothStepper)".

Select the SCU

ESS setup

Select the SCU



Browse to <https://warp9td.com>

Follow the directions to download the SCU application. There is also a great amount of background on setting up the ESS

ESS setup



Find the downloaded file and
double-click on it to run,

SCU setup

Start the SCU

Select Language


Select NEXT



ESS setup

Use the suggested folder


Select Next to install



ESS Setup


Note the instructions.

Select Next




ESS Setup

Select Finish




ESS Setup




Use option 3

ESS Setup

Select Easy Mode




ESS Setup



ESS Setup


Make sure that your ethernet cable is connected to the controller “PC” port and that the controller is turned on.

Then, select the “Files” drop down box.




ESS Setup

Select “Windows Performance Tuning” from the drop down box.



ESS Setup


Follow the instructions as shown.



ESS Setup

Select “apply all recommended actions”.

This will require you you restart your PC.




ESS Setup

After Your PC re-starts, run the Smooth Stepper Utility from your desktop, and you should see this screen.

Select “Close Window and SCU”

ESS setup is now complete.



ESS Setup is now complete

Machine Configuration

The ESS has 3 ports of 17 pins.

Most pins can be assigned as input or output.

The system has several control signals which are connected to an ESS pin

We must associate each signal with the correct pin.

All this data is stored in the Machine.ini file within your Profile.

There is a Machine.ini file on the memory stick supplied with this system.

You may simply copy it from the stick to replace the current file in your Profile.

Active Low

All signals in this system are digital, binary.

That means they may be a HIGH (typically +5V) or LOW (typically ground)

The system needs to know when the signal is TRUE, or ACTIVE

Active High means the signal is TRUE when it is HIGH

Active Low means the signal is TRUE when it is LOW.

There is no right or wrong, here, you just must use whichever choice the system designer chose.

Machine Configuration

If you want to fully understand the wiring of your machine use the following screens to configure the ESS pins.

The general process is to assign alias names to the pins in the ESS config and assign the alias names to the correct functions in Mach4.

The following screens refer to the tabs of the ESS Config screens.


Machine Configuration

From the main Mach4
screen menu bar

Select Configure-
>Plugins->ESS

Info screen will open

Work across the tabs



ESS Config Tab General

On the General tab leave all the settings as is.

Ethernet SmoothStepper (ESS) Configuration v285, Mach4 build 4.2.0.5036 - Instance 0

Info General Motors Spindle Laser Laser... Analog Pins Config Input Signals Output Signals Homing Probing Backlash HC

1) IP Address of the SmoothStepper
10.9.9.9

2) Buffer Size (seconds, max of 0.5)
0.1800

3) Plugin Frequency (Hz)
40

4) Velocity FIFO Buffer Ran Out of Data
☒ Show Hardware Velocity FIFO Ran Dry Msgs

5) Disable & EStop
☒ Charge Pump Runs In EStop
☒ Disable Expansion Port In Disable

6) Advanced Logging
☐ Enable Advanced Logging

7) When a Feed Hold Event turns an Output Pin
☒ OFF, prompt the operator before turning the output pin ON again
☒ ON, prompt the operator before turning the output pin OFF again

1) The motion controller's IP address will be 10.9.9.9 unless it was modified with the configurator.

2) Buffer Size defaults to 0.18. A smaller buffer size is more responsive to Feed Hold commands, but is more sensitive to the Velocity FIFO running out of data if your computer bogs down. Increase the buffer size to prevent the Velocity FIFO from running out of data. If you have received 'Velocity FIFO Ran Out of Data' messages, you should restart Mach4 after modifying the buffer size.

3) The plugin frequency is typically left at 40 Hz. Higher frequencies will let Mach respond to events faster, but will also force your PC to work harder to keep up (which is harder for slower computers to do).

4) This lets you choose to watch the Velocity FIFO, to make sure it does not Run Out of Data. We recommend you leave this checked. Running out of data may cause lost steps, and may indicate your PC is doing other tasks instead of servicing Mach4.

If you get these messages regularly, take these actions so critical data can make it to the motion controller in time:

- * Increase your Buffer Size (above).
- * Disconnect your PC from the internet and shut off WiFi.
- * Shut down all other programs on your PC.
- * Decrease your plugin Frequency to 30Hz or 20 Hz (above).
- * Visit Warp9TD.com and look at our FAQ Windows page to see how to optimize your PC further.
- * If your PC has less than 3 GB RAM (XP), 4GB RAM (Win7) or 8 GB RAM (Win10) you may want to increase your PC's RAM.

OK Cancel

ESS Config Tab Motors

We are using
Step/Dir motors
on all positions.

w9 Ethernet SmoothStepper (ESS) Configuration - v260

Info General **Motors** Spindle Laser Pins Config Input Signals Output Signals Homing Probing Ba

Axis Motors Settings: Step/Dir, Quadrature or CW/CCW

	Mode	Reported Feed Rate Smoothing (Sec)
Motor 0	Step/Dir	0.100
Motor 1	Step/Dir	0.100
Motor 2	Step/Dir	0.100
Motor 3	Step/Dir	0.100
Motor 4	Step/Dir	0.100
Motor 5	Step/Dir	0.100


☐ Enable AntiClunk Mode for Servo Motors

- 1) In the 'Output Signals' Tab, assign Aliases or Pins for each Motor used.
- 2) In Mach Config -> Motors, set up the parameters for each Motor used.
- 3) In Mach Config -> Axis Mapping, Enable your axes and assign Motors as Masters and/or slaves.

ESS Config Tab Spindle

We use a PWM
signal to control
spindle RPM.

Do not use PID
terms.



Ethernet SmoothStepper (ESS) Configuration v298, Mach4 build 4.2.0.5036 - Instance 0

Info General Motors **Spindle** Laser Laser... Analog Pins Config Input Signals Output Signals Homing Probing Backlash HC

1) Spindle Settings

Spindle Type: **PWM** Frequency, Hz: 300.00 ☐ Duty Cycle Zero at Min RPM

RPM: **Spindle Encoder A** Averaging 1.00 Sec ☒ Report Spindle RPM

Encoder Prescaler 1078 * Effective PPR 1 = 1078 Total Encoder Pulses/Rev

2) Spindle PID Settings (Only for PWM Drive Mode)

☐ Use PID ☐ Use PID For Threading ☐ SS_PID_LOG.csv

Kp 0.0000100 Ki 0.0000000 Kd 0.0000000

☐ Use PID Ceiling 120.00 % of commanded RPM ☐ Use PID Floor 95.00 %

1) Choose a Spindle Type of:

- * Relay or none - The spindle/router is controlled by relays or there is none
- * OB - Out of Band (Step/Dir, CW/CCW or Quadrature)
- * PWM - Pulse Width Modulation Spindle Speed control

The 'Output Signals' tab has dedicated Spindle pins for your system's relays:

- * Spindle Dir - Retains the current spindle direction even when the spindle stops. The state changes only with a direction change (prevents direction glitching)
- * Spindle On - Active when the spindle is active
- * Spindle Fwd - Only active when the spindle is running forwards/CW
- * Spindle Rev - Only active when the spindle is running in reverse/CCW

2) Spindle PID will adjust the PWM output, to try and hold the commanded RPM.

- * Kp is the constant proportional gain that corrects for the error amount.
- * Ki corrects for the error amount summed over time.
- * Kd corrects based upon the rate of change of the error amount.
- * Recommended initial values are Kp = 0.0000100 Ki = 0.0000000 Kd = 0.0000000
- * Index Pulses per Rev is '1' unless a slotted disk or encoder channel is used.

3) In the 'Output Signals' Tab, assign Aliases or Pins as needed for:

- * Spindle Motor PWM (Required)
- * Spindle Motor Dir (Optional)
- * Spindle On (Optional)
- * Spindle Fwd (Optional)

ESS Config Tab Pins Config

Scroll down on the Pins tab to see the Port 2 assignments.

Enter alias names for these pins.

Info General Motors Spindle Laser Laser... Analog Pins Config Input Signals Output Signals Homing Probing Backlash HC

1) Set the pins Active High (Red Arrow Up) or Active Low (Green Arrow Down).
 2) Give the Pins you are using an Alias: (P#-#) DESCRIPTION (This is the {Port#-Pin#} for the pin and a description of it).
 This makes it MUCH EASIER to identify which pins do what in the Input and Output signal tabs.
 3) Assign Noise Filtering, in us, for each input pin, if needed (see the 'Info' tab for more details).
 4) A Feed Hold or Stop (Stop, EStop, Disabled or Limit) event can set the Output state to 'Force ON', 'Force OFF', or 'No Change'.
 'No Change' means that the output is controlled by Mach4. With 'Force ON' and 'Force OFF' the ESS will force that desired state.
 5) Pins are always enabled, only Signals can be enabled or disabled. Connect pins as needed on the Input and Output signal tabs.

Port 2 Pins 2-9 Direction Port 3 Pins 2-9 Direction
☒ Inputs ☐ Outputs ☒ Inputs ☐ Outputs

	DIR	Active High/Low	Alias or Name	Noise Filtering	Stop State	Feed Hold State
Port1-Pin1	Out		Motor4 step {P1-1}	-----	No Change	No Change
Port1-Pin2	Out		Motor 0 step {P1-2}	-----	No Change	No Change
Port1-Pin3	Out		Motor 0 Dir {P1-3}	-----	No Change	No Change
Port1-Pin4	Out		Motor 1 Step {P1-4}	-----	No Change	No Change
Port1-Pin5	Out		Motor 1 Dir {P1-5}	-----	No Change	No Change
Port1-Pin6	Out		Motor 2 Step {P1-6}	-----	No Change	No Change
Port1-Pin7	Out		Motor 2 Dir {P1-7}	-----	No Change	No Change
Port1-Pin8	Out		Motor 3 Step {P1-8}	-----	No Change	No Change
Port1-Pin9	Out		Motor 3 Dir {P1-9}	-----	No Change	No Change
Port1-Pin10	In		Estop {P1-10}	0.00	-----	-----
Port1-Pin11	In		Motor 0+ +{P1-11}	0.00	-----	-----
Port1-Pin12	In		Motor 1+ +{P1-12}	0.00	-----	-----
Port1-Pin13	In		Motor2+ +{P1-13}	0.00	-----	-----
Port1-Pin14	Out		Spindle PWM {P1-14}	-----	No Change	No Change
Port1-Pin15	In		Probe {P1-15}	0.00	-----	-----
Port1-Pin16	Out		Spindle REV {P1-16}	-----	No Change	No Change
Port1-Pin17	Out		Motor 4 Dir {P1-17}	-----	No Change	No Change

OK Cancel

ESS Config Tab Pins Config

Continue entering
alias names as
per the screen to
the right.

Ethernet SmoothStepper (ESS) Configuration v298, Mach4 build 4.2.0.5036 - Instance 0

Info General Motors Spindle Laser Laser... Analog Pins Config Input Signals Output Signals Homing Probing Backlash HC

1) Set the pins Active High (Red Arrow Up) or Active Low (Green Arrow Down).
 2) Give the Pins you are using an Alias: {P#-#} DESCRIPTION (This is the {Port#-Pin#} for the pin and a description of it).
 This makes it MUCH EASIER to identify which pins do what in the Input and Output signal tabs.
 3) Assign Noise Filtering, in us, for each input pin, if needed (see the 'Info' tab for more details).
 4) A Feed Hold or Stop (Stop, EStop, Disabled or Limit) event can set the Output state to 'Force ON', 'Force OFF', or 'No Change'.
 'No Change' means that the output is controlled by Mach4. With 'Force ON' and 'Force OFF' the ESS will force that desired state.
 5) Pins are always enabled, only Signals can be enabled or disabled. Connect pins as needed on the Input and Output signal tabs.

Port 2 Pins 2-9 Direction Port 3 Pins 2-9 Direction
☒ Inputs ☐ Outputs ☒ Inputs ☐ Outputs

	DIR	Active High/Low	Alias or Name	Noise Filtering	Stop State	Feed Hold State
Port1-Pin15	In		PROBE {P1-15}	0.00	----	----
Port1-Pin16	Out		Spindle REV {P1-16}	----	No Change	No Change
Port1-Pin17	Out		Motor 4 Dir {P1-17}	----	No Change	No Change
Port2-Pin1	Out		{P2-1}	----	No Change	No Change
Port2-Pin2	In		{P2-2} Spindle Encoder A	0.00	----	----
Port2-Pin3	In		{P2-3} Spindle Encoder B	0.00	----	----
Port2-Pin4	In		{P2-4} Spindle Encoder Index	0.00	----	----
Port2-Pin5	In		{P2-5}	0.00	----	----
Port2-Pin6	In		{P2-6}	0.00	----	----
Port2-Pin7	In		{P2-7}	0.00	----	----
Port2-Pin8	In		{P2-8}	0.00	----	----
Port2-Pin9	In		{P2-9}	0.00	----	----
Port2-Pin10	In		{P2-10}	0.00	----	----
Port2-Pin11	In		{P2-11}	0.00	----	----
Port2-Pin12	In		{P2-12}	0.00	----	----
Port2-Pin13	In		{P2-13}	0.00	----	----
Port2-Pin14	Out		{P2-14}	----	No Change	No Change

OK Cancel

ESS Config Tab Pins Config

This system does not include a coolant pump.

Charge Pump is a safety feature, commonly known as a “watchdog timer”. If Mach4 should crash the control logic will shutdown all motion.

Ethernet SmoothStepper (ESS) Configuration v298, Mach4 build 4.2.0.5036 - Instance 0

Info General Motors Spindle Laser Laser... Analog Pins Config Input Signals Output Signals Homing Probing Backlash HC

1) Set the pins Active High (Red Arrow Up) or Active Low (Green Arrow Down).
2) Give the Pins you are using an Alias: (P#-#) DESCRIPTION (This is the (Port#-Pin#) for the pin and a description of it) .
This makes it MUCH EASIER to identify which pins do what in the Input and Output signal tabs.
3) Assign Noise Filtering, in us, for each input pin, if needed (see the 'Info' tab for more details).
4) A Feed Hold or Stop (Stop, EStop, Disabled or Limit) event can set the Output state to 'Force ON', 'Force OFF', or 'No Change'.
'No Change' means that the output is controlled by Mach4. With 'Force ON' and 'Force OFF' the ESS will force that desired state.
5) Pins are always enabled, only Signals can be enabled or disabled. Connect pins as needed on the Input and Output signal tabs.

Port 2 Pins 2-9 Direction Port 3 Pins 2-9 Direction
☒ Inputs ☐ Outputs ☒ Inputs ☐ Outputs

	DIR	Active High/Low	Alias or Name	Noise Filtering	Stop State	Feed Hold State
Port2-Pin15	In	↑	{P2-15}	0.00	-----	-----
Port2-Pin16	Out	↑	Coolant On {P2-16}	-----	No Change	No Change
Port2-Pin17	Out	↑	Charge Pump {P2-17}	-----	No Change	No Change
Port3-Pin1	Out	↑	{P3-1}	-----	No Change	No Change
Port3-Pin2	In	↑	{P3-2}	0.00	-----	-----
Port3-Pin3	In	↑	{P3-3}	0.00	-----	-----
Port3-Pin4	In	↑	{P3-4}	0.00	-----	-----
Port3-Pin5	In	↑	{P3-5}	0.00	-----	-----
Port3-Pin6	In	↑	{P3-6}	0.00	-----	-----
Port3-Pin7	In	↑	{P3-7}	0.00	-----	-----
Port3-Pin8	In	↑	{P3-8}	0.00	-----	-----
Port3-Pin9	In	↑	{P3-9}	0.00	-----	-----
Port3-Pin10	In	↑	{P3-10}	0.00	-----	-----
Port3-Pin11	In	↑	{P3-11}	0.00	-----	-----
Port3-Pin12	In	↑	{P3-12}	0.00	-----	-----
Port3-Pin13	In	↑	{P3-13}	0.00	-----	-----

OK Cancel

ESS Config Tab Pins Config

This shows the
remainder of the Pins
Config Tab

Ethernet SmoothStepper (ESS) Configuration v298, Mach4 build 4.2.0.5036 - Instance 0

Info General Motors Spindle Laser Laser... Analog Pins Config Input Signals Output Signals Homing Probing Backlash HC

1) Set the pins Active High (Red Arrow Up) or Active Low (Green Arrow Down).
 2) Give the Pins you are using an Alias: {P#-#} DESCRIPTION (This is the {Port#-Pin#} for the pin and a description of it).
 This makes it MUCH EASIER to identify which pins do what in the Input and Output signal tabs.
 3) Assign Noise Filtering, in us, for each input pin, if needed (see the 'Info' tab for more details).
 4) A Feed Hold or Stop (Stop, EStop, Disabled or Limit) event can set the Output state to 'Force ON', 'Force OFF', or 'No Change'.
 'No Change' means that the output is controlled by Mach4. With 'Force ON' and 'Force OFF' the ESS will force that desired state.
 5) Pins are always enabled, only Signals can be enabled or disabled. Connect pins as needed on the Input and Output signal tabs.

Port 2 Pins 2-9 Direction Port 3 Pins 2-9 Direction
☒ Inputs ☐ Outputs ☒ Inputs ☐ Outputs

	DIR	Active High/Low	Alias or Name	Noise Filtering	Stop State	Feed Hold State
Port3-Pin2	In		{P3-2}	0.00	-----	-----
Port3-Pin3	In		{P3-3}	0.00	-----	-----
Port3-Pin4	In		{P3-4}	0.00	-----	-----
Port3-Pin5	In		{P3-5}	0.00	-----	-----
Port3-Pin6	In		{P3-6}	0.00	-----	-----
Port3-Pin7	In		{P3-7}	0.00	-----	-----
Port3-Pin8	In		{P3-8}	0.00	-----	-----
Port3-Pin9	In		{P3-9}	0.00	-----	-----
Port3-Pin10	In		{P3-10}	0.00	-----	-----
Port3-Pin11	In		{P3-11}	0.00	-----	-----
Port3-Pin12	In		{P3-12}	0.00	-----	-----
Port3-Pin13	In		{P3-13}	0.00	-----	-----
Port3-Pin14	Out		{P3-14}	-----	No Change	No Change
Port3-Pin15	In		{P3-15}	0.00	-----	-----
Port3-Pin16	Out		{P3-16}	-----	No Change	No Change
Port3-Pin17	Out		{P3-17}	-----	No Change	No Change

OK Cancel

ESS Config Tab Input Signals

Limit switches and
the E-stop button,
etc

Ethernet SmoothStepper (ESS) Configuration v298, Mach4 build 4.2.0.5036 - Instance 0

Info General Motors Spindle Laser Laser... Analog Pins Config **Input Signals** Output Signals Homing Probing Backlash HC

1) When you enable an input signal here, it will automatically be enabled and mapped into Mach.
2) An Input Pin (or Alias) may be assigned to multiple Input Signals.

	Enable	Mach Mapping	Mapped Pin
E-Stop		ESS	Estop {P1-10}
Motor 0 Home		ESS	Motor 0+ {(P1-11)}
Motor 1 Home		ESS	Motor 1+ {(P1-12)}
Motor 2 Home		ESS	Motor2+ {(P1-13)}
Motor 3 Home			
Motor 4 Home			
Motor 5 Home			
Motor 0 ++ Limit		ESS	Motor 0+ {(P1-11)}
Motor 1 ++ Limit			
Motor 2 ++ Limit		ESS	Motor2+ {(P1-13)}
Motor 3 ++ Limit			
Motor 4 ++ Limit			
Motor 5 ++ Limit			
Motor 0 -- Limit		ESS	Motor 0+ {(P1-11)}
Motor 1 -- Limit			
Motor 2 -- Limit			
Motor 3 -- Limit			
Motor 4 -- Limit			
Motor 5 -- Limit			
Motor 0 Index		ESS-only	
Motor 1 Index		ESS-onlv	

OK Cancel

ESS Config Tab Input Signals

Spindle and encoder
input signals

Ethernet SmoothStepper (ESS) Configuration v298, Mach4 build 4.2.0.5036 - Instance 0

Info General Motors Spindle Laser Laser... Analog Pins Config **Input Signals** Output Signals Homing Probing Backlash HC

1) When you enable an input signal here, it will automatically be enabled and mapped into Mach.
2) An Input Pin (or Alias) may be assigned to multiple Input Signals.


	Enable	Mach Mapping	Mapped Pin
Encoder 3 Phase B		ESS-only	
Encoder 4 Phase A		ESS-only	
Encoder 4 Phase B		ESS-only	
Encoder 5 Phase A		ESS-only	
Encoder 5 Phase B		ESS-only	
Encoder Aux 0 Phase A (MPG or other)		ESS-only	
Encoder Aux 0 Phase B (MPG or other)		ESS-only	
Encoder Aux 1 Phase A (MPG or other)		ESS-only	
Encoder Aux 1 Phase B (MPG or other)		ESS-only	
Encoder Aux 2 Phase A (MPG or other)		ESS-only	
Encoder Aux 2 Phase B (MPG or other)		ESS-only	
Encoder Spindle Phase A		ESS-only	{P2-2} Spindle Encoder A
Encoder Spindle Phase B		ESS-only	{P2-3} Spindle Encoder B
Spindle Index (RPM Input)		ESS	{P2-4} Spindle Encoder Index
Spindle At Speed			
Spindle At Zero			
Probe (G31 or G31.0)			
Probe 1 (G31.1)			
Probe 2 (G31.2)			
Probe 3 (G31.3)			
THC On (Arc Okay)			

OK Cancel

ESS Config Tab

Input Signals

There are no additional changes to be made on the “Input Signals” tab



ESS Config Tab Output Signals

These outputs drive the motors.

For a lathe Motor 3 through 4 are not needed and will not be used, but it's OK to have these defined.

Ethernet SmoothStepper (ESS) Configuration v298, Mach4 build 4.2.0.5036 - Instance 0

Info General Motors Spindle Laser Laser... Analog Pins Config Input Signals Output Signals Homing Probing Backlash HC

1) An Output Pin (or Alias) may only be assigned to a single Output Signal.
2) An Output Signal may have up to 3 Output Pins (or Aliases) assigned to it:
* When enabled in this window, only 'Mapped Pin1' will be enabled and mapped into Mach.
* 'Mapped Pin2' and 'Mapped Pin3' will still receive the same Output Signal as 'Mapped Pin1', but will not be referenced in Mach.

	Enable	Mach Mapping	Pin1 Mapping	Pin2 Mapping	Pin3 Mapping
Motor 0 Step		ESS-only	Motor 0 step (P1-2)		
Motor 0 Dir		ESS-only	Motor 0 Dir (P1-3)		
Motor 1 Step		ESS-only	Motor 1 Step (P1-4)		
Motor 1 Dir		ESS-only	Motor 1 Dir (P1-5)		
Motor 2 Step		ESS-only	Motor 2 Step (P1-6)		
Motor 2 Dir		ESS-only	Motor 2 Dir (P1-7)		
Motor 3 Step		ESS-only	Motor 3 Step (P1-8)		
Motor 3 Dir		ESS-only	Motor 3 Dir (P1-9)		
Motor 4 Step		ESS-only			
Motor 4 Dir		ESS-only			
Motor 5 Step		ESS-only			
Motor 5 Dir		ESS-only			
Motor 0 Enable		ESS			
Motor 1 Enable		ESS			
Motor 2 Enable		ESS			
Motor 3 Enable		ESS			
Motor 4 Enable		ESS			
Motor 5 Enable		ESS			
ESS, XY Feed Rate PWM		ESS-only			
ESS, Z Feed Rate PWM		ESS-only			

OK Cancel

ESS Config Tab Output Signals

Spindle and charge
pump outputs.

Ethernet SmoothStepper (ESS) Configuration v298, Mach4 build 4.2.0.5036 - Instance 0

Info General Motors Spindle Laser Laser... Analog Pins Config Input Signals Output Signals Homing Probing Backlash HC

1) An Output Pin (or Alias) may only be assigned to a single Output Signal.
2) An Output Signal may have up to 3 Output Pins (or Aliases) assigned to it:
* When enabled in this window, only 'Mapped Pin1' will be enabled and mapped into Mach.
* 'Mapped Pin2' and 'Mapped Pin3' will still receive the same Output Signal as 'Mapped Pin1', but will not be referenced in Mach.

	Enable	Mach Mapping	Pin1 Mapping	Pin2 Mapping	Pin3 Mapping
ESS, XY Feed Rate PWM		ESS-only			
Laser PWM/XY Vel PWM/AOut1		ESS-only			
Spindle Motor PWM Or AOut 0		ESS-only	Spindle PWM {P1-14}		
Spindle Motor Dir		ESS-only	Spindle REV {P1-16}		
Spindle On		ESS			
Spindle Fwd		ESS			
Spindle Rev		ESS			
Alarm		ESS			
Charge Pump		ESS-only	Charge Pump {P2-17}		
Coolant, Flood (M08, M09)		ESS	Coolant On {P2-16}		
Coolant, Mist (M07, M09)		ESS			
Current Hi/Low		ESS			
Cut Recovery		ESS			
Digitize Trigger		ESS			
Dist To Go		ESS			
Dwell		ESS			
Feed Hold		ESS			
Feed Hold Disabled		ESS			
F.H. Not Allowed (4720+)		ESS			
Feed Rate Override		ESS			

OK Cancel

ESS Config Tab

Output Signals

There are no additional changes to the “Output Signals” tab

Ethernet SmoothStepper (ESS) Configuration v298, Mach4 build 4.2.0.5036 - Instance 0

Info General Motors Spindle Laser Laser... Analog Pins Config Input Signals Output Signals Homing Probing Backlash HC

1) An Output Pin (or Alias) may only be assigned to a single Output Signal.
2) An Output Signal may have up to 3 Output Pins (or Aliases) assigned to it:
* When enabled in this window, only 'Mapped Pin1' will be enabled and mapped into Mach.
* 'Mapped Pin2' and 'Mapped Pin3' will still receive the same Output Signal as 'Mapped Pin1', but will not be referenced in Mach.

	Enable	Mach Mapping	Pin1 Mapping	Pin2 Mapping	Pin3 Mapping
Feed Hold	<input checked="" type="checkbox"/>	ESS			
Feed Hold Disabled	<input checked="" type="checkbox"/>	ESS			
F.H. Not Allowed (4720+)	<input checked="" type="checkbox"/>	ESS			
Feed Rate Override	<input checked="" type="checkbox"/>	ESS			
Feed Rate Override Disabled	<input checked="" type="checkbox"/>	ESS			
FRO Not Allowed (4720+)	<input checked="" type="checkbox"/>	ESS			
GCode Complete (4802+)	<input checked="" type="checkbox"/>	ESS			
GCode Running	<input checked="" type="checkbox"/>	ESS			
ESS, Is Moving	<input checked="" type="checkbox"/>	ESS-only			
Jog Cont	<input checked="" type="checkbox"/>	ESS			
Jog Enabled	<input checked="" type="checkbox"/>	ESS			
Jog Inc	<input checked="" type="checkbox"/>	ESS			
Jog MPG	<input checked="" type="checkbox"/>	ESS			
Limit Override	<input checked="" type="checkbox"/>	ESS			
Machine Coord	<input checked="" type="checkbox"/>	ESS			
Machine Enabled	<input checked="" type="checkbox"/>	ESS			
Machine Idle	<input checked="" type="checkbox"/>	ESS			
Machine Probing	<input checked="" type="checkbox"/>	ESS			
Parts Finished	<input checked="" type="checkbox"/>	ESS			
Rapid Rate Override	<input checked="" type="checkbox"/>	ESS			

OK Cancel

ESS Config Tab Homing

The motors in this system do not have an index signal.

Home operations approach the switch at higher speed, then back off slowly to make accurate location.

1) Homing is enabled for a Motor 'N', when the 'Input Signals' tab has:
* 'Motor N Home' Enabled with a green check.
* 'Motor N Home' has an assigned 'Mapped Pin'.

2) If you have encoders with an index pulse, you may enable homing to a motor's index pin by:
* Place a green check in 'Home to Motor's Index Pin'.
* Make sure that the index signal is enabled for that Motor.

	Home Pin (Automatically Populated from 'Input Signals' tab)	Approach Velocity (Units/Min)	Backoff Velocity (Units/Min)	Home To Motor's Index Pin	Rotational Axis Motor Index Pin (Automatically Populated from 'Input Signals' tab)	After Backoff Move (Units)
Motor 0	Motor 0+{P1-11}	20.0	20.0	<input checked="" type="checkbox"/>		0.0000
Motor 1	Motor 1+{P1-12}	20.0	20.0	<input checked="" type="checkbox"/>		0.0000
Motor 2	Motor 2+{P1-13}	20.0	20.0	<input checked="" type="checkbox"/>		0.0000
Motor 3		1.0	1.0	<input checked="" type="checkbox"/>		0.0000
Motor 4		1.0	1.0	<input checked="" type="checkbox"/>		0.0000
Motor 5		1.0	1.0	<input checked="" type="checkbox"/>		0.0000

This number sets the velocity of the home move.
20 is a reasonable value for the LMS5100

ESS Config Tab

Backlash

We use ballscrews with near zero backlash.

Mach4 can compensate for backlash when it exists.

Leave these values unchanged.

W9 Ethernet SmoothStepper (ESS) Configuration - v260

Info General Motors Spindle Laser Pins Config Input Signals Output Signals Homing Probing Backlash HC

1) Backlash Compensation Options

☒ Use Backlash Compensation ☐ Show Backlash Comp Messages in Log

	Enabled	Backlash Amount (Read Only)	Mach Velocity (Units/Min)	Mach Acceleration (Units/Sec^2)	Use Custom Values?	Custom Velocity (Units/Min)	Custom Acceleration (Units/Sec^2)
Motor 0		0.0000	501.0000	20.0000		10.0000	1.0000
Motor 1		0.0000	502.0000	20.0700		10.0000	1.0000
Motor 2		0.0000	125.0000	5.0200		10.0000	1.0000
Motor 3		0.0000	500.0000	20.0000		10.0000	1.0000
Motor 4		0.0000	15.0000	10.0000		10.0000	1.0000
Motor 5		0.0000	15.0000	10.0000		10.0000	1.0000

1) When 'Use Backlash Compensation' is enabled, the SmoothStepper will perform Backlash Compensation (B.C.). Fixing backlash through software is never as effective as removing backlash with better hardware.

* The first column, 'Enabled', should be CHECKED if it is a normal motion axis, or if you want that motor's movements to affect B.C.

Associating ESS and Mach4 connections.

We have now assigned a name to each signal connected to the ESS

Now we need to use these names to configure Mach4.

In the ESS we simply refer to motors 0-6.

Mach4 needs to associate a motor with an axis.


Select Configure->Control from Mach4 main screen.

Configure Mach4 signals- Motors

Each motor must be configured for step per unit and speed.

The motors maximum velocity is set here.

Test these values carefully to be sure you are not pushing the machine too fast.



Configure Mach4 signals- Motors


On the prototype machine we found these values

Axis	Step		Vel	Accel
X	10144.5	200	10	
Z	8130	200	15	

You should make accurate measurement by commanding a set distance and measuring the actual move.

Configure Mach Aux Positions


Enable each motor
and associate the
Axis with motor.



Configure Mach Axis Mapping

Enable each motor
and associate the
Axis with motor.

Note Mach4 supports
slave motors when
one motor is not
powerful enough for
an axis (large routers)


































































Configure Mach Input Signals

Associate input pins
with motors home
position.

Control Configuration Mach4Lathe:0

Defaults General Plugins Motors Aux. Positions Axis Mapping Homing/SoftLimits Input Signals Output Signals Analog Inputs Analog Outputs MPGs

	Mapping Enabled	Device	Input Name	Active Low	Log Enabled	User Description
Input #0						
Input #1						
Input #2						
Input #3						
Input #4						
Input #5						
Input #6						
Input #7						
Input #8						
Input #9						
Input #10						
Input #11						
Input #12						
Input #13						
Input #14						
Input #15						
Input #16						
Input #17						
Input #18						
Input #19						
Input #20						

OK Cancel Apply

Configure Mach Input Signals

Scroll down to Motor
Home area of the sheet
and make these
changes.

Control Configuration Mach4Lathe:0

Defaults General Plugins Motors Aux. Positions Axis Mapping Homing/SoftLimits Input Signals Output Signals Analog Inputs Analog Outputs MPGs

	Mapping Enabled	Device	Input Name	Active Low	Log Enabled	User Description
Input #63						
Motor 0 Home		ESS	Motor 0+ +{P1-11}			
Motor 1 Home		ESS	Motor 1+ +{P1-12}			
Motor 2 Home		ESS	Motor2+ +{P1-13}			
Motor 3 Home						
Motor 4 Home						
Motor 5 Home						
Motor 6 Home						
Motor 7 Home						
Motor 8 Home						
Motor 9 Home						
Motor 10 Home						
Motor 11 Home						
Motor 12 Home						
Motor 13 Home						
Motor 14 Home						
Motor 15 Home						
Motor 16 Home						
Motor 17 Home						
Motor 18 Home						
Motor 19 Home						

OK Cancel Apply

Configure Mach Input Signals

Scroll down to Motor++ area of the sheet and make these changes.

Control Configuration Mach4Lathe:0


Defaults General Plugins Motors Aux. Positions Axis Mapping Homing/SoftLimits Input Signals Output Signals Analog Inputs Analog Outputs MPGs

	Mapping Enabled	Device	Input Name	Active Low	Log Enabled	User Description
Motor 31 Home						
Motor 0 ++		ESS	Motor 0++{P1-11}			
Motor 1 ++						
Motor 2 ++		ESS	Motor2++{P1-13}			
Motor 3 ++						
Motor 4 ++						
Motor 5 ++						
Motor 6 ++						
Motor 7 ++						
Motor 8 ++						
Motor 9 ++						
Motor 10 ++						
Motor 11 ++						
Motor 12 ++						
Motor 13 ++						
Motor 14 ++						
Motor 15 ++						
Motor 16 ++						
Motor 17 ++						
Motor 18 ++						
Motor 19 ++						

OK Cancel Apply

Configure Mach Input Signals

Scroll down to Motor—
area of the sheet and
make these changes.



Configure Mach Input Signals

Scroll down to Index (Encoder) area of the sheet and make these changes.

Control Configuration Mach4Lathe:0

Defaults General Plugins Motors Aux. Positions Axis Mapping Homing/SoftLimits Input Signals Output Signals Analog Inputs Analog Outputs MPGs


	Mapping Enabled	Device	Input Name	Active Low	Log Enabled	User Description
Motor 30 --						
Motor 31 --						
Digitize						
Index		ESS	{P2-4} Spindle Encoder Index			
Limit Override						
E-Stop		ESS	Estop {P1-10}			
THC On						
THC Up						
THC Down						
Timing						
Jog X+						
Jog X-						
Jog Y+						
Jog Y-						
Jog Z+						
Jog Z-						
Jog A+						
Jog A-						
Jog B+						
Jog B-						
Jog C+						

OK Cancel Apply

Configure Mach Input Signals


There are no more
changes to be made to
“Input Signals”

Note that there are 127
inputs available within
Mach4 software.



Configure Mach Output Signals

There are no changes
to the “Output Signals”
tab



Configure Mach Tools

These values are appropriate for a lathe.

Control Configuration Mach4Lathe:0

Aux. Positions Axis Mapping Homing/SoftLimits Input Signals Output Signals Analog Inputs Analog Outputs MPGs Tools Spindle Tool Path

Max Tools
99

Tool Change Type
☐ T on M6 line is next tool
☒ T on M6 line is tool to use.

Tool Life Cancel Number
100

Tool Life Restart M Code
0

Tool Life Type Default
☒ Cycle
☐ Time

Tool Skip Group
☒ Current Group
☐ Specified

Tool Exchange Reset Signal
☒ Clears specified group.
☐ Clears all groups.

Life Count Override (time only)
☒ Disabled
☐ Enabled

M99 Expired Condition
☒ TLCHB signal is not output.
☐ TLCHB signal is output.

TLCHB Signal
☒ Output for each tool.
☐ Output for the last tool in a group.

OK Cancel Apply

Configure Mach Spindle

Set a Min and Max speed for the lathe.

This value must be set to 0

These two values must be set as shown

The lathe has no belt ranges.

Set MAX spindle RPM

Control Configuration Mach4Lathe:0

Aux. Positions Axis Mapping Homing/SoftLimits Input Signals Output Signals Analog Inputs Analog Outputs MPGs Tools Spindle Tool Path

	MinRPM	MaxRPM	Accel Time	Decel Time	FeedBack Ratio	Reversed
0	0.00	3500.00	2.00	2.00	1.00000	
1	0.00	500.00	2.00	2.00	1.00000	
2	0.00	0.00	0.00	0.00	1.00000	
3	0.00	0.00	0.00	0.00	1.00000	
4	0.00	0.00	0.00	0.00	1.00000	
5	0.00	0.00	0.00	0.00	1.00000	
6	0.00	0.00	0.00	0.00	1.00000	
7	0.00	0.00	0.00	0.00	1.00000	
8	0.00	0.00	0.00	0.00	1.00000	
9	0.00	0.00	0.00	0.00	1.00000	
10	0.00	0.00	0.00	0.00	1.00000	
11	0.00	0.00	0.00	0.00	1.00000	
12	0.00	0.00	0.00	0.00	1.00000	
13	0.00	0.00	0.00	0.00	1.00000	
14	0.00	0.00	0.00	0.00	1.00000	
15	0.00	0.00	0.00	0.00	1.00000	
16	0.00	0.00	0.00	0.00	1.00000	
17	0.00	0.00	0.00	0.00	1.00000	
18	0.00	0.00	0.00	0.00	1.00000	

Max Spindle Motor RPM: 3600.00 ☐ Wait on spindle to stabilize to 90 percent.

Spindle Override Delay: 25 (ms)

Step/Dir Spindle Axis: None (Axis must be enabled and mapped.) ☐ Enable Step/Dir Spindle rigid tapping.

OK Cancel Apply

Generating a Mach4 license key

Mach4 is licensed software.

A license is needed for each machine.

The license is keyed to the PC it is running on.

Each system in this project was provided with a registration code that is needed to activate a license.

Generating a Mach4 license key

Click Help->About on the Mach4 menu bar


Copy this PC ID to clipboard.

On the Machsupport.com site paste the ID when asked.

A key file will be E-mailed to you.

Load it here.

DEMO will be changed after license is installed.



Mach4 license

After the license key is successfully loaded Mach4 will change references to DEMO to your user ID.

There are some restrictions built into Mach4 DEMO that will be removed after the license is installed.

Certain changes to the PC, replacing hard drive or net card, will change the PC_ID

This will require getting a new key from Machsupport.com

Backup

Mach4 stores all configuration values and some current operation data in a file `C:\Mach4Hobby\Profiles\MyLathe\Machine.ini`.

This file is saved during shutdown.

A copy is also stored in the folder `\Backups` in the Profile folder.

A revolving list of 20 backups are saved with a 2 digit number appended.

If you ever have a problem and want to go back to a previous version simply move the file from `\Backups` to replace the current `\Machine.ini`, removing the 2 digit number.

Calibrating Spindle Speed


The spindle speed is controlled by a PWM signal generated by Mach4.

A circuit on the C82 control board converts this pulse stream to a varying DC voltage between 0 and +10 volts.

Set the machine to run at its mid-speed, ##### RPM

You can use the MDI command S#### M3 to set the speed.

Adjust this pot to set the speed.



Spindle Direction control


The C82 board has outputs for Forward and Reverse run of the spindle motor.

There are two common schemes for managing these signals, one commonly used in the US, another in Europe.

The C82 board has two jumpers to set this.

If set to INT the motor will only run in one direction.

For this control the ~~jumper~~ should be set to the US position.



Congratulations

You should now be ready to make parts with your new Lathe.

Good Luck!